

Jetmobile™

information traceability, security and mobility

SecureJet™
Authentication 

Jetmobile solutions are available in most countries, worldwide

Gold Integrator 2006 in India:



KAPS IT Solutions Pvt. Ltd.
www.jetprints.in
corporate@jetprints.in
Ph: 080-25500942
Fax: 080-25502394

Copyright 2006 Jetmobile
All rights reserved.

All trademarks are the property of their respective owner.

Information in this document is believed to be accurate and reliable at the time of printing, but Jetmobile assumes no responsibility for any errors that may appear in this document.

Information and product specifications are subject to change without notice.

P/N JMDSS.JPX0606

Business partner



SecureJet™ 5 Auth-PX

Proximity badges authentication for hp MFP, Printers and Digital Senders

If you need to control access to hp MultiFunction Printers (MFPs) and printers in your organization, install SecureJet Auth-PX. Users will then use their corporate proximity badge to get access to the device functions such as email, fax, copy or scan. No more login/password to type on the MFP front panel!

Up to 1 million badges

SecureJet Auth-PX is a sophisticated badge reader directly connected to the hp LaserJet MFP motherboard, combined with a software running inside the printer.

Up to 1 million users can be recognized per MFP. The badge and users list can be securely stored on every MFP hard drive or validated against LDAP or Active Directory upon authentication*. SecureJet Auth-PX offers the fastest authentication at the best price.

Authenticate for MFP applications

The administrator can define for what MFP functions users must show their badge to get access. Upon badge number validation, the MFP knows about the user name, login and email address. That information is then used by the MFP application such as email sending (FROM field), copy tracking or secure printing to reclaim the user print jobs.

Authenticate for Secure Printing

On printers and MFPs, Authentication can apply to SecureJet Secure Mobile Printing. Users can reclaim their print jobs stored on the printer/MFP disk or on remote servers, by simply showing their badge. *This requires the SecureJet Print SMP and PS modules.*

Usable with all MFP functions

Authentication can apply to fax, email, copy, print jobs, scan to folder, DSS Workflow™, hp Autostore™, job tracking and any other MFP function.



Supported Proximity badges

HID Prox, HID iCLASS, Mifare, DESFire, Hitag1, EM-Marin and Legic SecureJet Auth-PX readers are available. Please contact us for projects involving other badges.

Simple to install

SecureJet Auth-PX connects directly inside the MFP without external box.

System requirements

Supports most hp LaserJet printers, hp LaserJet MFPs and Digital Senders.

Full list at www.jetmobile.com, with device-specific pre-requirements.

Package includes

SecureJet Auth-PX reader
Cable routing adhesive brackets
MFP internal card
Power supply and setup guide

Regulation

CE and FCC Certified
WEEE and RoHS compliant

Part number: SJPX00**

*: SecureJet Print PS module required